

CO₂ Capture Process Using Phase-Changing Absorbents



**GE Global Research
GE Energy
University of Pittsburgh**



ARPA-E Contract: DE-AR0000084



**2011 NETL CO₂ Capture
Technology Meeting
August 22-26, 2011**



Team Members

GRC

Bob Perry
Mike O'Brien
Sarah Genovese
Ben Wood
Tiffany Westendorf
Matt Meketa
Tom Perry
Rachel Farnum
John McDermott
Irina Sultanova



GEE

Ravi-Kumar Vipperla
Lisa Wichmann
Sam Draper



GE Energy




U Pitt

Bob Enick
Lei Hong
Deepak Tapriyal




Program Summary



- Develop cost-efficient process utilizing a phase-changing sorbent
- Build off of prior DOE/NETL program using amino-silicones

Increase in COE over Non-Capture Case for prior NETL Project




- GAP-1/TEG system
- Significant benefit with low water system
- Additional advantage with lower ΔH_{rxn} and C_p
- Calculated 41% increase in COE vs 74% for optimized MEA system

R. Vippera




imagination at work

ARPA-E Phase Change (Driver – Economics)




Conventional Solvent Systems



- 30% power lost in conventional MEA process (70-80% increase in COE)
- Significant portion of that due to heating/condensing water
- Low water based processes reduce energy/cost (~40% COE increase)
- Eliminate all non-reactive co-solvents (potential of ~30% COE increase)

Phase Change Concept




- 1 Make the solid (Solvent development)**
- 2 Collect the solid (Solid isolation)**
- 3 Move the solid (Solids transport)**
- 4 Regenerate the solvent (CO₂ desorption and recycle)**





Solvent Development

- Primary amines rapidly react with CO_2 to form carbamate salts




- Systematically vary chemistry and structure for optimal reactivity
- Representative materials found that:

- are low viscosity liquids
 - produce solids on exposure to CO_2
 - have high CO_2 uptake
 - thermally reversible
- 
- The chemical structure of 2-aminoethanol is shown, consisting of a two-carbon chain with a hydroxyl group (OH) on the first carbon and an amino group (NH
- ₂
-) on the second carbon.




GAP-0/1

13.1 - 17.3% CO₂ uptake


 $M'_3 T'$

18.8 % CO₂ uptake



M'D'M'

17.8 % CO₂ uptake



cyclic

15.5 % CO₂ uptake

Solvent Development


- Powder formation with dry CO₂
- Flue gas contains water
- What happens with wet CO₂?

Absorbant	Dry CO ₂			Wet CO ₂			% of Dry
	% Wt Gain	% of Theoretical	Salt Form	% Wt Gain	% of Theoretical	Salt Form	
GAP-0	17.3	98	Powder	18.4	104	Chunky Solid	106
GAP-1	13.1	96	Powder	14.1	103	Sticky Wax	108
M'D'M'	17.8	99	Powder	16.6	92	Glass	93
M'3T'	18.8	103	Powder	17.4	95.5	Sticky Gum	93
Cyclic Diamine	15.5	82	Powder	20.7	109	Powder	134

M. O'Brien

- 3 materials maintain solid form with saturated CO₂
- No loss of capture capacity
- Scaling up materials for spray drying



Vapor Pressure




R. Farnum, T. Perry, S. Genovese

- All aminosilicone materials tested exhibited vapor pressures < MEA

Thermal Stability







R. Farnum



- Excellent thermal stability
- Major decomposition products are higher homologues
- On-going experiments with stabilizers


Thermal Stability




R. Farnum

• Demonstrated poor thermal stability

Carbamate Salt Formation




GAP-0



- GAP-0 chosen as GEN 1 solvent
- Acceptable CO_2 loading
- High boiling point
- Reversibility
- Fast reaction rate
- Thermal stability


Solid Formation and Isolation





B. Enick
D. Tapiyal
L. Hong



- Spray drier with co-current CO_2 flow
- Nearly instantaneous solid formation
- 50-100 g sample size
- Additional instrument procured




PSD by Image Analysis



Mean size = 4.3 μm
 Aspect ratio 0.6-1.0 (most 0.75-0.9)









Sieve measures agglomerate size
 (as expected)



- For solids handling want ~ 500 μm particle size
- Need much larger particles


Sample images

Images are on the same scale



- All particles are ~ same size
- Mean size <50 μ m


Image Analysis



- Confirmation of particle size similarity
- Mean size <50 μm
- Single exception of M'D'M'

T. Westendorf
J. Grande

Options for solid transport



- contingent upon physical characteristics of solid
- density, shape, cohesiveness, moisture content, thermal stability
- integration between absorber and desorber
- low pressure to high pressure


T. Westendorf

Dry Solids Transfer


	Posimetric Pump	Screw Conveyor	Lockhopper	Piston Pump
Batch/continuous	Continuous	Continuous	Semi-continuous	Semi-continuous
Charge cycle	Hopper flow of freely-flowable solids into unit			
Pressure seal	Compressed solids plug	Compressed solids extruded through die at barrel exit	Pressure swing chamber isolation valves	Solids compressed in piston chamber
Solids discharge	Mechanical rotation of pump spool	Mechanical rotation of screw	Hopper flow, assisted by pressurized gas	Mechanical discharge
Advantages	Designed for low wear	Heat exchange integration possible	Low risk of premature phase change	Simple design
Limitations	New operability challenges for phase-changing solids	Difficult to adapt to high delivery pressure; high wear of screw components	Large volumes of pressurizing gas needed; complex design	High wear of piston components

- Multiple options available for solids handling

Desorption




- Neat GAP-0 data
- >14% to <4%
- ~10% dynamic range




S. Genovese

Desorption




- TGA shows 3 events
- Onset at ~70 °C
- Major loss 90-110 °C
- DSC indicates 2 events
- Looking at desorption kinetics

- TGA/MS confirms only CO₂ loss
- No decomposition products
- Examining DSC/TGA profiles to differentiate phase changes from decarboxylation process




XRD



- GAP-0 carbamate is highly crystalline

B. Wood, C. Dosch, M. Meketa


XRD



- GAP-0 carbamate is highly crystalline
- Water does not disrupt matrix

B. Wood, C. Dosch, M. Meketa

XRD




- GAP-0 carbamate is highly crystalline
- Water does not disrupt matrix
- Diluent does not affect XL structure

B. Wood, C. Dosch, M. Meketa

XRD


- How much does heat of crystallization affect ΔH_{rxn} ?




- GAP-0 carbamate is highly crystalline
- Water does not disrupt matrix
- Diluent does not affect XL structure

B. Wood, C. Dosch, M. Meketa

Process Schematic




CO₂ Island - Process Flow Diagram
Dry Solids Transfer



- Absorb CO₂ at 50 °C/1 atm
- Collect solid and pump to desorber
- Heat at 120 °C under pressure to release CO₂
- Lean solvent returned to absorber
- CO₂ compressed for storage

Preliminary COE Waterfall





R. Vipperla

- Large savings with low water
- Higher net loading of CO₂ provides decrease COE
- Optimized plant operation (desorption, HX) offers savings

Plant Modeling and COE Calculations

- Elimination of water and co-solvent
- Increased CO₂ capture capacity
- Higher desorption pressure/temp
- Substantial decrease in energy use
- Smaller COE increase



**Target for
decreased
COE**

Moving Forward

- Complete solvent development/down-selection
- Ratify action of stabilizers
- Finish unit operations designs
- Conclude construction of absorber, solids transfer and desorber units
- Confirm operation of unit ops
- Integrate unit operations into COE calculations
- Validate original premise/assumptions
- Acquire funding for scale-up process

Acknowledgement. The information, data, or work presented herein was funded in part by the Advanced Research Projects Agency – Energy (ARPA-E), U.S. Department of Energy, under Award Number DE-AR0000084 and DOE- NETL under Award Number DE-NT0005310.

Disclaimer. The information, data, or work presented herein was funded in part by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

Thank you